



R I M A G E™

# Attention Everest 600 Users

After installing this retransfer ribbon you must reset your printing preferences.

1. From the Windows Desktop, select **Start > Printers and Faxes**.
2. In the *Printers and Faxes* window, right-click on the **Everest 600 printer** listed.
3. Select **Printing Preferences** from the dropdown menu.
4. Select the **Utility** tab, then **Status Monitor...** The *Rimage Everest 600 - Status Monitor* screen displays.
5. Select the **Options...** button.
6. Select the **Use 500 print retransfer ribbon** checkbox.
7. Select **Reset prints** and close the *Status Monitor, Printing Preferences* and *Printers and Faxes* windows.

The Everest 600 printer is ready for use.